



Routine Maintenance Instructions

Hickman Edge Systems, LLC. manufactured coping and fascia do not require regular maintenance, but the system, like all parts of the roof, should be inspected periodically. During inspection, the edge metal should be checked to see that the cap and cleat/clip are securely engaged, splices have not migrated, and corners and end caps have not shifted.

Finishes based on Kynar 500® are also virtually maintenance-free and non-staining, due to their low coefficient of friction. Normal dirt and grime are washed away with every rain. Should a more thorough cleaning be desired, the finish may be cleaned with a mild soap and water solution and rinsed with clean water. For more detailed information or if your building is in coastal areas, see Hickman's Painted Material Care and Cleaning Guide.

Thank you for choosing our products and please call should you have any questions.