




ELEVATE ANCHORGARD® MB HG FASCIA

BUILT-UP OR MODIFIED VERSION

INSTALLATION INSTRUCTIONS





1. Roof Membrane

Follow the general recommendations for membrane treatment at the roof edge. Position modified membrane over the roof edge and down the outside face as shown.

NOTES:

- 1) May require a "sacrificial" flashing strip. (refer to drawing 2A and 2B) please check with the manufacturer prior to installation.
- 2) In cold weather, the back of the flashing strip should be treated appropriately and shorter lengths of strips should be used.

IMPORTANT! Outside edge of treated wood nailer(s) (minimum 2 x 4) shall be aligned flush with or extend slightly past outermost edge of wall. Fascia is for use as a perimeter securement on roof designs where the product is not installed in a waterline.



2. Roof Edge

Install "sacrificial" flashing strips according to the manufacturer's recommendations. Install the largest manageable lengths possible, to minimize overlaps under the anchor bar. Following the applicable flashing method (hot mop, cold adhesive, etc..), according to manufacturer's recommendations, lay the flashing strip into place, extending a minimum 8" onto the roof membrane and down the outside face of wall, 1/2" beyond the wood nailer.



ELEVATE
26 CENTURY BLVD.
SUITE 205
NASHVILLE, TN 37214

CONTACT YOUR LOCAL ELEVATE REPRESENTATIVE

DATE: 03/22/23

DRN BY: MLM

CKD BY: MM

SHT.# 1 OF 4

DWG# 13110-5665


J



ELEVATE ANCHORGARD® MB HG FASCIA


BUILT-UP OR MODIFIED VERSION

INSTALLATION INSTRUCTIONS




3. Miter & Scupper Anchor Bar (Preparation)

Lay miters and scuppers on deck with outside face down. Be sure aluminum anchor bar is clean and free of dirt or dust. Cover the entire flange with 1/4" thick cement to back of anchor bar as shown. This application is required along the full length of each miter anchor bar.




4. Anchor Bar Splice Plates

Apply mastic or sealant to each splice plate as shown. Ensure the sealant is placed into the grooves along the spacer.



5. Miter Bar Installation

Install bar miters using fasteners and driver bit provided. fasten anchor bar miters to nailer with one bar splice under each end of miter insuring ends are snug. The anchor bar must insert into the grooves in the splice plate. Next, install scuppers with flashing cement, fasteners and splices.



6. Anchor Bar Installation

Position 12' anchor bar sections with applied non-curing sealant as shown in step 3, overlapping anchor bar splice plate. Allow $\frac{3}{8}$ " space between anchor bars. Install anchor bar splice plate at other end of bar section. Fasten anchor bar 12" O.C. through slotted holes using provided fasteners. The anchor bars must insert into the grooves in the splice plates. Field cut sections as necessary.

CAUTION! Installers shall wear protective eye wear to prevent injury. Do not over-drive fasteners, as stripping can occur at high driver torque. Recommended driving tool: 600 - 800 rpm electric drill equipped with depth-sensing nose-piece to prevent driving and stripout. Do not use impact type tool.



ELEVATE
26 CENTURY BLVD.
SUITE 205
NASHVILLE, TN 37214

CONTACT YOUR LOCAL ELEVATE REPRESENTATIVE

DATE: 03/22/23
DRN BY: MLM
CKD BY: MM

SHT.# 2 OF 4

DWG# 13110-5665


J



ELEVATE ANCHORGARD® MB HG FASCIA


BUILT-UP OR MODIFIED VERSION

INSTALLATION INSTRUCTIONS



7. Fascia Miter Covers

Install miter covers first. Insert one splice plate under each end of the two piece miter cover. Engage cover with 90° tab onto bottom of anchor bar and rotate miter cover up and over anchor bar miter until engaged along entire length of the anchor bar. Repeat steps to install miter cover without the 90° tab.



8. Fascia Covers

Install 12'-0" fascia cover sections. Allow a 3/8" gap between fascia cover sections. Insert one splice plate under far end of each fascia cover section. Install cover by hooking lower edge of cover onto anchor bar and rotating cover up and over anchor bar until engaged along entire length of cover section. Continue to install cover sections in this manner, field cutting where necessary using a fine tooth hacksaw.

IMPORTANT!

Be sure to remove protective plastic film prior to installing each fascia section.



ELEVATE
26 CENTURY BLVD.
SUITE 205
NASHVILLE, TN 37214

CONTACT YOUR LOCAL ELEVATE REPRESENTATIVE

DATE: 03/22/23

DRN BY: MLM

CKD BY: MM

SHT.# 3 OF 4

DWG# 13110-5665

J




ELEVATE ANCHORGARD® MB HG FASCIA

BUILT-UP OR MODIFIED VERSION


COMPONENT LIST




FASCIA COVER
12' - 0" LENGTHS




ANCHOR BAR
12' - 0" LENGTHS




ANCHOR BAR SPLICE
3 1/2" WIDE W/ 3/4" EPDM GASKET




SCREW W/ WASHER




OUTSIDE MITER BAR



INSIDE MITER BAR



OUTSIDE MITER FASCIA COVER



INSIDE MITER FASCIA COVER



ELEVATE
26 CENTURY BLVD.
SUITE 205
NASHVILLE, TN 37214
CONTACT YOUR LOCAL ELEVATE REPRESENTATIVE

DATE: 03/22/23
DRN BY: MLM
CKD BY: MM

SHT.# 4 OF 4
DWG# 13110-5665

J