


# ARCH TO STRAIGHT COPING MITER

## ANGLE MEASUREMENT INSTRUCTION SHEET

1. Cut a straightedge 16" long.
2. Lay the straightedge against the top of the arched portion of the miter area. Align the straightedge at the corner of the miter area and at the top edge of the arch (as illustrated).
3. Measure the angle as shown. Record this measurement in the box provided.
4. Fill in the general information below and fax this sheet back.

### RIGHT HAND MITER SHOWN



### ELEVATION VIEW FROM ROOF SIDE

### PROJECT INFORMATION:

(PROJECT NAME)

(ARCHITECT)

(ROOFING CONTRACTOR)

(REPRESENTATIVE/DISTRIBUTOR)



ELEVATE  
26 CENTURY BLVD.  
SUITE 205  
NASHVILLE, TN 37214  
CONTACT YOUR LOCAL ELEVATE REPRESENTATIVE

DATE: 03/20/23  
DRN BY: MLM  
CKD BY: MM

SHT.# \_\_\_ OF \_\_\_  
DWG# 13511-15727  
B